


# How everything works...

## Oven user guide

Your oven has three dials. To operate the oven or grill, all three must be used.


- The middle dial (timer) must be moved for your oven to work. Turn it anticlockwise to use the oven for an unlimited time or turn it clockwise to set a specific cooking time.
- Next select the oven or grill function you want to use (see diagram below).
  1. Off
  2. Light
  3. Defrost
  4. Oven
  5. Grill
  6. Grill with Fan
- Finally turn the temperature dial to the desired temperature and you're ready to cook!





## Dishwasher user guide

- Select the On/Off key to turn on the appliance.
- **Programme Selection / Programme Cancel Key**  
Select the programme by pressing the desired programme key.  
Press and hold the Start / Pause / Cancel key for 3 seconds to cancel the running programme.
- **Function Keys**  
If you press any of the Function keys during programme selection or time delay selection, the indicator of the function will flash if the programme you have selected supports the selected function.  
To cancel the selected function, press the function key again.
- **Programme Selection**
  1. Press the On/Off button to turn on your machine.
  2. Refer to the Programme Table to determine a washing programme suitable for your dishes.
  3. Selected programme will start when you close the door of your machine.
  4. If the door is opened during a cycle, press start again to resume the cycle then close the door.



1. On/Off Key
2. Rinse Aid Indicator
3. Programme Indicators / Water Overflow Warning (P1 Flashes)
4. Fast+ Function
5. Extra Drying Function
6. Delayed Start Key
7. Time Delay Countdown Indicator
8. Start / Pause / Cancel Key
9. Salt Indicator
10. Water Cut-off Indicator



# Ooni Koda pizza oven user guide



This pizza oven is for outdoor use only. Please only use on the outdoor kitchen worktop.

Forest Holidays

- Ooni Koda has been designed to cook your pizza at perfect cooking temperature – 400C! Children and pets must be kept at a safe distance while Ooni Koda is hot.
- The pizza oven should not be left running for extended periods without cooking. If you are taking a break from cooking, give your pizza oven a break too by switching it off.

## Tools for cooking



### Infrared Thermometer

Get an instant accurate temperature reading by aiming the laser at the middle of the stone baking board. The Ooni Infrared Thermometer is the must have tool for gauging the temperature of the stone baking board before you begin cooking. It will allow you to achieve a perfect base to your pizza.



### Peel

Our peels have been designed specifically for use with Ooni ovens and are sleek and easy to transport and store. Having an additional peel helps to speed up the pizza supply chain so that you can invite more friends and family to enjoy your exceptional food.



### Cast Iron

Cast iron is perfect for seared meat, baked fish and delicious roast vegetables. The Ooni cast iron range is designed to withstand the high temperatures inside Ooni Koda.

## Lighting your Ooni Koda

7. Gas terminal for attaching your propane source.

- Open the gas valve on the tank.
- Push in and slowly turn the control knob anti clockwise until you hear a click and the burner ignites.
- Continue to push in the control knob for 5 seconds after ignition and then release.
- Ooni Koda should run quietly when lit. If you hear a roaring noise from the gas burner, switch off the gas for 5 minutes and re-light.
- If the flames go out, turn off the gas supply and detach Ooni Koda from the tank. Leave for 5 minutes before re-attaching and re-igniting.



Push, slowly turn and hold for 5 seconds to light



Min. power



Max. power



Off



### Top Tips

- The custom-made stone inside your Ooni Koda oven retains heat and absorbs moisture from the dough, giving a perfectly cooked base.
- The intense heat in the oven will cook your pizza in 60 seconds.
- Use high quality flour and fresh ingredients. Less is more for your toppings.
- Stretch your dough out thinly, leaving a-centimetre-wide crust.
- Flour the peel (pizza tray) before putting your pizza on it to preventing it sticking once cooked.
- Aim for 400C in the centre of your stone baking board before you add your pizza.
- If your toppings are cooked before your base turn down the flames and the stone baking board will continue to cook from below.
- Rotate your pizza every 20-30 seconds to aim for a nice even char on your crusts.

### Care and Maintenance

- Cleaning the inside of the Ooni Koda is easy. Simply run at top temperature for 30 minutes to burn off excess food. Once cool, the inside can be wiped down with dry paper towels.
- The outer shell can be wiped down with a damp cloth. Please do not use abrasive cleaning products or harsh chemicals on the pizza oven.
- The stone baking board is not dishwasher safe. To clean, wash the board with warm, soapy water, rinse off and dry the board in a oven for a minimum of 3 hours at 140C.

